RANCH HAND 1-800-366-9712

INSTALLATION INSTRUCTIONS

For HEADACHE RACKS

- 1. Place the bed rails or short rails on the truck bed.
- 2. Set the headache rack on the front of the truck bed. The headache rack gusset will mount to the outside of the bed rail or short rail gusset.
- 3. Use the ½" x 1 ½" carriage bolts to mount the gussets together and use the ½" x 1" carriage bolts to mount the angle bracket of the bed rail or short rail to the angle iron of the headache rack.

RANCH HAND 1-800-366-9712 INSTALLATION INSTRUCTIONS For HEADACHE RACKS

- 1. Place the bed rails or short rails on the truck bed.
- 2. Set the headache rack on the front of the truck bed. The headache rack gusset will mount to the outside of the bed rail or short rail gusset.
- 3. Use the ½" x 1 ½" carriage bolts to mount the gussets together and use the ½" x 1" carriage bolts to mount the angle bracket of the bed rail or short rail to the angle iron of the headache rack.

RANCH HAND 1-800-366-9712 INSTALLATION INSTRUCTIONS For HEADACHE RACKS

- 1. Place the bed rails or short rails on the truck bed.
- 2. Set the headache rack on the front of the truck bed. The headache rack gusset will mount to the outside of the bed rail or short rail gusset.
- 3. Use the ½" x 1 ½" carriage bolts to mount the gussets together and use the ½" x 1" carriage bolts to mount the angle bracket of the bed rail or short rail to the angle iron of the headache rack.

RANCH HAND 1-800-366-9712 INSTALLATION INSTRUCTIONS For HEADACHE RACKS

- 1. Place the bed rails or short rails on the truck bed.
- 2. Set the headache rack on the front of the truck bed. The headache rack gusset will mount to the outside of the bed rail or short rail gusset.
- 3. Use the ½" x 1 ½" carriage bolts to mount the gussets together and use the ½" x 1" carriage bolts to mount the angle bracket of the bed rail or short rail to the angle iron of the headache rack.